



AMPBOX 27K

65W, 27000mAh Power Bank



User Manual

Package Contents :

1. Power Bank
2. Charging Cable
3. User Manual

Introduction :

Ampbox 27K is a compact yet highly functional power bank capable of delivering up to 65 Watts of power to meet all your charging requirements.

Ampbox 27K

1. LCD Digital Display
2. Type-C 1 Input & Output Port
3. Wake Up Button
4. USB Port 1
5. USB Port 2
6. Type-C 2 Input & Output Port



Main Features :

- Suitable for nearly all kinds of mobile phones and electronic devices with a USB port.
- Built-in IC protection to prevent over-charge, over-discharge, over-current, and short circuit.

- Intelligent power management solution for steadiness and high efficiency.
- LCD power indicator lights and power/status button.
- High-grade plastic housing.

Technical Specifications :


Battery Capacity	: 27,000mAh 3.7V (99.9Wh)
Type-C Input 1	: DC 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A
Type-C Input 2	: DC 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A
USB-A Output 1	: DC 5V/3A, 9V/2A, 12V/1.5A
USB-A Output 2	: DC 5V/3A, 9V/2A, 12V/1.5A
Total Output	: 65W Max

Operating Instructions :


Charging Your Device: Connect your device to an output port of your power bank using a compatible USB cable.

NOTE:

- In some cases, it might be required to press the power-on button once.
- Use the included cable to charge compatible devices through the USB-A output of your power bank.
- You can also use other cables to charge many other devices with different types of ports.



- **Charging your Power Bank :** Connect a power supply to an input port of your Power Bank using a compatible USB cable. This Power Bank can be charged with a USB power adapter or other power sources, such as a USB computer port. To ensure a rapid and stable power supply, please use a quick charge-enabled power adapter to charge this battery.



While charging the battery, the power indication light will display the current charge status; each light represents 25% of capacity. When the LCD display shows the battery has reached full capacity, click the power button. The Power Bank will be turned on, and the LCD display will show how much power it has.

Troubleshooting:

1. Unable to charge Power Bank

- Check if the power adapter is the right one and if the cable is not broken.

2. Power Bank unable to charge your Device

- Power Bank capacity is running too low. Charge your Power Bank first.
- Ensure the correct connection between your Power Bank and the device (input port instead of output).
- Power Bank failure.

Usage Tips:

- Please charge your power bank at least once every 3 months if not in use for a long time.
- Make sure to check that the voltage of the device you intend to charge is compatible with this power bank.
- While in use, your power bank may become slightly warm. This is normal as long as the temperature does not surpass 60°C.

- Keep your power bank dry; do not wipe with powerful chemical cleaners.
- After your device is fully charged, please unplug it from the power bank since it will keep consuming electricity at a slow rate.

Precautions:

- Do not attempt to repair the product yourself.
- Do not alter or modify the product in any way.
- Only use the charger for its intended purpose.
- Keep it out of the reach of children and pets.
- Do not expose it to extreme temperatures, liquids/moisture, or mechanical pressure.
- Avoid dropping to prevent internal damage.
- Only use in a dry area.
- The charger is maintenance-free. For cleaning, use a dry cloth only and do not use any chemicals or cleaning agents.

DOS and DON'Ts

- Make sure the Power Bank is fully charged prior to use.
- Use a cable suitable for your device when charging it from the Power Bank.

- When charging the Power Bank, it is recommended that you use the included charging cable.
- Recharge the Power Bank as soon as possible to avoid shortening the battery life.
- The battery should be charged at least every three months to avoid shortening the battery life.
- Do not wash the Power Bank with corrosive cleaner.



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245 , 011-42413131

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



For E-waste & ROHS compliance refer to <http://www.portronics.com/ewaste.html>