



- 1.1 Please read Manual carefully before you use the projector.
- 1.2 To ensure stable power supply, please use national standard power cable and power cord with grounding.
- 1.3 Please use the right power cord for the projector, improper power cord may cause damage to the
- 1.4 Please do not disassemble the machine yourself, otherwise the company will not undertake warranty
- 1.5 Do not look directly at the projector lens while the machine is working, it might cause damage to your eyes.
- 1.6 To prevent clogging the projector vents, do not cover them with cloth, carpet or other materials.
- 1.7 This projector does not have waterproof function, please keep it away from rain, moisture and other items containing liquid such as vase, cup, etc.
- 1.8 To prevent electric shock, please keep the projector away from rain, water or moisture.
- 1.9 Cut off the power supply if do not use this projector for a lona time.
- 1.10 Use the original foam or other unit-shock material to protect projector if you need transport this projector.
- 1.11 If you find the projector have problems, please contact with the supplier, do not repair by yourself.
- 1.12 To extend the projector life span and protect your eyesight, we suggest you may have a break after 3-4 hours using.

2 Interface Introduction




Remote Control Introduction



4 Media Connection

4.1 USB Connection

Connect the USB with the content to the projector USB port, select Media, you can select movie, music, photo, text on the list.





4.2 HDMI equipment connection

HDMI interface could connect to computers and other devices with HDMI output interface. After connected, choose the channel HDMI.






HDMI


The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

4.3 3.5mm audio device connect

Connect 3.5mm earphone and speaker equipment.



5 Projector Connection Introduction








Please refer to the instructions of your specific devices for details.
*Please make sure the mobile phone and the projector are connected with the same Wi-Fi network.

*If you have more than one projector, they will each have different names.

6 Miracast Connection

6.1 Miracast

- 1. Press the source button on remote.
- 2. Select multi screen 3. Then, select cast screen.



P.S. Please take the latest software version as final.

6.2 Miracast

6.2.1 Android Miracast

Select Android Miracast under the home page on the projector, turn on the display setting or multi-screen interaction on your Android phone. Next, select the corresponding projector name.

*Different Android devices have different multi-screen interaction settings.



6.2.2 IOS Screen Mirroring

*NOTE: For miracast/screen mirroring on iOS devices both the projector and device should be connected to home wifi network.



mobile devices video app, then go to the TV screen mode and select the corresponding projector ID, you will get the screen image on the projector.

*NOTE: For best view/output use the projector in a dark room.



Setup Menu



7.2 System setting

use remote control for a long time.



Open the home page- Setting, find the Picture Setting, you can set up the projection mode, image scaling, color range aspect ratio, picture mode of the projector.

Projection Mode	
Image Scaling	
Color Range	
Aspect Ratio	
Picture Mode	

Open the home page - Setting, find the system setting, you can set up the OSD language, software update (USB), restore factory default, sleep timer of the projector.

1. To avoid power shortage please do not mix up with the old and new battery.

2. To avoid battery leakage corrosion please take the battery out if do not

3. When using the remote control please align the remote control signal

4. For better usage kindly use the remote from the backside of the projector.

ransmitter to the projector's infrared signal reception window.



Open the home page - Setting, find the other setting, you can set up the OSD timer, wifi setting and Bluetooth.



7.3.1 Enter the interface of OSD timer as the

following picture, select the time that needed to be set, then you can choose the time of setup menu palying.



7.3.2 Enter the WIFI setting interface as shown in the picture below, select the wifi network you need to connect.



7.3.3 How to connect to BT mode?

1. Click the power button.

- 2. The login window for BT MODE opens.
- 4. Use the remote arrow key to choose a device.



7.3.4 Press the power button of remote or projector, select the amplifier mode, and click the panel on, BT name of the device will be displayed in the upper right corner, turn on the Bluetooth interface of the mobile

3. Click on BT MODE/BT Name on the top right of screen. phone to search for available Bluetooth device, click the Bluetooth device you want to connect, then you



By Electronic Focus



9 Product Parameter

Imaging technology

Resolution

Unit size

Projector radio


Maximum compatible resolution 1920*1080 Focus mode Electronic focus Projection distance 1.2-5.7 M Screen size 40-200 inches 16:9 Aspect ratio Power input 19V/3.42A USB*1/HDM**I***1 Output Earphone 4Ω31N*2 Speaker

TFT LCD

1280*720

Ø118.179mm

0.79KG



Note: Due to optics error of 3%, the data above is for reference only, please use actual measurement when install the device.

PORTRONICS



BEEM 400 HD Projector With Screen Mirroring

www.portronics.com

PORTRONICS

For Support Visit: www.portronics.com Email: help@portronics.com Contact No.: +91 9555245245, 011-42413131 (Working Hrs.: Monday - Saturday 10:00am - 6:00pm)



For F-Waste & ROHS compliance refer to www.portronics.com/ewaste


6.2.3 DLNA

Select DLNA mode on the projector. next access your



7.3.Other settings





can use the projector with the amplifier mode.

8 Adjust The Image Clarity

After the projection image is well adjusted, press the press-key (5) (6) to adjust the image clarity.