

1. Please read the user manual carefully before using the product and store the user manual properly for future reference.
2. This document provides basic function operation instructions, please refer to the "User Manual" on the home page of the system for detailed operation and other functions.

PACKAGE CONTENTS

- ⇒ Projector x 1
- ⇒ Remote Control x 1
- ⇒ Power Cord x 1
- ⇒ User Manual x 1

TURNING THE PROJECTOR ON & OFF

1. Powering On: After the projector is connected to a power source, press the power button of the device or the power button on the remote control to turn on the projector.
2. Powering Off: Press the power button on the device or remote control and the "Shutdown" icon will pop-up on the projection screen. Confirm again to shut down the projector.
3. Indicator light description: The indicator lights are in two colors and the different operating states of the projector are indicated by a colour change.
 - When the red colour light indicator is on, the projector is in standby mode.
 - When the blue colour indicator light is on, the projector is in working mode.
 - If the device is kept idle for more than fifteen minutes, it may automatically enter standby mode.

ADJUSTING THE PROJECTOR FOCUS


Automatic Focus:

1. The projector will automatically focus every time it is turned on and whenever the projector is moved, it will automatically adjust the projection focal length to maintain a clear image.
2. To disable the auto-focus function, you must turn off the "Auto Focus" option in the "Projection Settings" section of the settings interface.
3. Sometimes after the projector auto focuses, because of different personal visual perception, there may be differences in the judgment of the clarity of the projection picture. You can use the focus buttons on the remote control to make minor corrections to the projection clarity, so that the projection picture can achieve the required optimal viewing effect.

Electronic Focus:

1. You can also use the remote control to adjust the focus manually / electronically. To focus quicker, long press the F+/F- key on the remote control, and a focus icon will appear in the center of the projection screen and rotate rapidly in clockwise or anti-clockwise direction.
2. To focus precisely, press the F+/F- key on the remote control to adjust the focus, and the focus icon in the center of the projection screen will change with the direction of F+/F- until the screen is clear.

REMOTE CONTROL



Attention: Please aim the remote control behind the projector for using. Please remove the batteries if you are not going to use the remote control for a long time.

VIEWING USER MANUAL APP


Click the Up arrow button on the remote control while on the homepage to pop up a shortcut operation pop-up window. Open the "Instructions" to browse the product instructions.




PLEASE NOTE

Please read this manual carefully before use and keep it for future reference.



- Avoid exposure of the projector to dust, water / moisture and extreme temperatures.



- This device is not dustproof or waterproof, regularly clean projector vents to avoid cooling malfunction.
- Please use high quality power cord and under specified rated power supply.
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.



- Do not cover the vents of projector and ensure it is in a well-ventilated area when in use, positioned at least 2 feet away from the wall from behind. Heating will reduce the life of projector and cause danger.



- Please cut off the power if the projector is out of use for long time.
- Users or third-party professionals should not attempt to disassemble the projector for testing and maintenance, in which case, the warranty will be void.
- For optimal viewing performance, the projector should be positioned at a height of 5 feet from the ground and at least 5 feet away from the wall or screen in the front.
- Use the remote control from behind the projector for convenient operation.

Note: Any damage caused by physical impact, water/ liquid, fire, etc. caused by the customer or nature shall not be covered under warranty.

Only product design, feature and functionality-related faults can be considered. As per the brand's discretion, the product is eligible for repair and not for replacement, during the warranty period.



www.portronics.com

For Support

Visit : www.portronics.com

E-mail : help@portronics.com


Contact No.: +91 9555245245

(Working Hours: Monday - Saturday, 10:00am - 6:00pm)



E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance refer to www.portronics.com/ewaste



BEEM 530
SMART LED PROJECTOR

User Manual