



# SLIDEMATE

2.4 GHZ MULTIFUNCTION WIRELESS PRESENTER

User Manual

## 1 Product Introduction

SlideMate is an electronic product specially designed for computers and multimedia projection. In addition to its traditional laser pointer function, it provides remote control for paging down, paging up, hyperlink navigation, and volume control on your computer. It is an ideal choice for various occasions, including meetings, e-learning, conferences, and more.

### 1.1 Accessories List


- PPT Presenter- 1pc
- USB Receiver- 1pc
- AAA Battery- 2pcs
- User Manual & Warranty Card- 1pc

## 2 Product Specifications

- 2.1 Main material : ABS
- 2.2 Working frequency : 2.4GHZ
- 2.3 Control distance : >30M
- 2.4 Laser type : Class III<5mW
- 2.5 Laser color : Red
- 2.6 Laser wavelength : 650nm/525nm.
- 2.7 Power supply battery : 2 AAA 7th battery
- 2.8 Battery type : Mercury-free alkaline battery
- 2.9 Nominal voltage : 3V
- 2.10 Operating system : Windows/Mac
- 2.11 Compatible interfaces : USB2.0 USB3.0
- 2.12 Product size : 110mmX45mmX30.5mm
- 2.13 Product weight : 35g (Exclude battery)

## 3. Instructions for use

### 3.1 Buttons and Functions



No.	Button	Function
1	Power Switch	Control the power of Slidemate
2	Page Down Button	Supports page scrolling down
3	Page Up Button	Supports page scrolling up
4	Laser Button	Controls the laser of Slidemate
5	Hyperlink Button	Single-click to select a hyperlink and double-click to open it
6	Return Key	Single-click to go back or hyperlink, double-click the 'S' key to pause the PPT loop
7	Full-Screen Button	Click to view in full-screen mode
8	Desktop Button	Return to the desktop
9	ESC Button	Single-click to execute the ESC key function, double-click the space bar to pause the video
10	Laser Light	Indicates the working status of the laser

## Key Combination

Press the Up and Down buttons simultaneously to switch between modes:

- Mode 1:** Up and Down Arrow
- Mode 2:** Left and Right Arrows
- Mode 3:** Page Up/Page Down

## Match Code

First, insert the receiver into the USB port of your computer. Then, press and hold the page-turning button while moving the power switch to the ON position. The indicator light will blink and stop to complete the pairing process.

## 3.2 Function Description

3.2.1. Insert the bottom receiver into the computer's USB port, and then insert the battery into the product. Open the PPT, Keynote, or PDF file. When everything is ready, you can begin the demonstration.

3.2.2. If the product emits a laser but doesn't have the page-turning function, first, insert the receiver into the computer's USB port. Then, press and hold the page-turning button while moving the toggle switch to the ON position. The indicator light will blink and establish a connection.

3.2.3. For Windows PPT, use Page Up/Page Down or the Up and Down arrows to control page turning. For Mac OS Keynote, use the left and right arrows to control page turning. To switch between function modes, press and hold the Up and Down keys for 2 seconds.

## 4 Caution

- Do not disassemble, bump, crush, or expose to fire.
- If severe swelling occurs, discontinue use immediately.
- Avoid placing in high-temperature environments.
- Never use the laser to shine directly into the eyes of people or animals.