



FREEDOM 15 Plus

Desktop Wireless Charger + Mobile Stand

User Manual

PACKAGING CONTENTS


- Wireless Charger X 1
- Type C Cable X 1
- User Manual X 1

PRODUCT INTRODUCTION

Thank you for choosing the Portronics Freedom 15 Plus desktop wireless charger, an exceptional product that combines a sleek and compact design with the convenience of wireless charging. With its Qi compatibility, it provides safe and high-speed charging for all Qi-enabled smartphones. Enjoy the freedom of a clutter-free charging solution with the Portronics Freedom 15 Plus!

PRODUCT DESCRIPTION

- (A)** Wireless phone charging area
- (B)** LED Indicator Light
- (C)** Type C Input Port
Connect the Type C cable to the Type C input port



CONNECTING TO POWER

1. Connect the Type C cable to the adapter (adapter not included).
2. Turn on the adapter switch. The LED light indicator will start glowing automatically.

WIRELESS CHARGING YOUR SMARTPHONE

1. Once the adapter is connected to a main power supply, and the LED indicator flashes blue & red once, then turns light red - wireless charging is ready.
2. Place the mobile phone in the center of the charging surface. Once placed, the Blue LED indicator will turn on, indicating charging.
3. Check the charging icon on your mobile device screen to know the charging status.
4. When the mobile device is fully charged, the Blue indicator light will remain on.
5. If the indicator light is flashing, it indicates a Foreign Object Detection (FOD) status. In such cases, try removing your mobile phone case.

SPECIFICATIONS

Wireless Charger Input	: 5.0V/9V
Wireless Charger Output (Max)	: 15W/10W/7.5W/5W
Wireless Distance	: 8MM
Efficiency	: 75%
Dimension	: W66mm X D85mm X H103mm
Weight	: 119g

GUIDELINES

- For a better experience, it is recommended to use a high-power adapter above 20W.
- This product has input over-current and over-voltage protection. Improper use may result in shutdown or reduced output power. Please check for abnormalities or improper use of equipment.
- Maintain an operating environment temperature of 0-50°C. Avoid placing the product in water, fire, or extreme temperatures (<-20°C or >40°C), and keep it out of children's reach.
- Clean the surface with a dry soft cloth; avoid using chemicals, soap, or detergent.
- Improper use or placement may damage the product and reduce its lifespan, which is not covered by the warranty.