

# IRON BEATS

With Karaoke Mic



Welcome to the world of Portronics- It's time to elevate your music listening experience with Iron Beats Speaker. We recommend you to go through the User manual to understand it's working properly.

**Specification:**

- Bluetooth version: 5.3
- Output power: 250W
- Frequency response: 100Hz-20KHz
- Signal to noise ratio: >=85dB
- Bluetooth range: 10M
- Max memory USB/SD: 32GB
- USB charging: DC 5V
- Battery capacity: 7.4V 3600mAh
- Charging via USB port (PC): 3-4 hours
- Size: 265X260X600 mm
- Weight: 7.82 kg


**Package Contents:**

- 1 x Party Speaker
- 1 x Charging cable
- 1 x Wireless MIC
- 1 x Remote 1 N

**How To Connect Bluetooth Device:**

Turn on the unit and switch on your mobile Bluetooth, then search for the speaker Portronics Iron Beats and pair the device. Once device is paired, Bluetooth will automatically connect when unit is turned on subsequently

**Product Details:**



1. OFF/ON Key: To turn ON/OFF the speaker.
2. MIC-Volume: To control Mic volume
3. Volume: To control Master Volume
4. Echo- : Press to decrease echo
5. Echo+: Press to increase echo
6. Light button: Press to select RGB light mode
7. Mute: Press to mute the volume
8. DC 5V: Plug the charging cable to the speaker and connect other end USB port to the power source. (DC 5V or Type-C slot)
9. USB slot: Used to read the Mp3 files in FAT32 format with maximum size of 32GB.
10. TF slot: Used to read the Mp3 files in FAT32 format with maximum size of 32GB.

11. 3.5mm jack: Aux-in, connect with MP3 or other outlet via audio cable.
12. 6.35mm jack: Microphone In
13. Play/Pause: Under USB/TF/Bluetooth mode, short press for play and pause.
14. Mode: To change mode during USB/TF, Bluetooth and Aux-in mode.
15. Previous: USB/TF/Bluetooth: Press to move previous track.
16. Next: USB/TF/Bluetooth: Press to move next track.
17. MIC Press to change MIC effect.

**Remote Function:**

1. Start by Key: To turn ON/OFF the speaker.
2. EQ : Select different modes like ,Normal, Focal, Classic & Jazz.
3. Mode : To Select mode USB/TF/Bluetooth and Aux-in mode.
4. Mute: Press to mute the volume .
5. Repeat: Press to Repeat Song.
6. Volume -: To Decrease the Master Volume.
7. Volume +: To Increase Master Volume.
8. Previous: USB/TF/Bluetooth: Press to move Previous track.
9. Next: USB/TF/Bluetooth: Press to move to next track
10. Play/Pause: Under USB/TF/Bluetooth mode, short press for play and pause.
11. Light button: Press to select RGB light mode.
12. Numeric Key : To select a any song directly by pressing the numeric key .

**AUX IN:**

AUX-IN, Using the audio cable into AUX jack, press M to switch to Aux in Mode.

**Note:** In the AUX IN mode, it couldn't shift Prev and Next by Bluetooth speaker, but can control by connection device.



**BLUETOOTH:**

Turn on the speaker, It comes into the Bluetooth mode directly. After pair the device, it can play the music, Short Press ▶| to Play/Pause, press ◀◀ and ▶▶ to Prev and Next track.

TWS operation: 1. Turn on both same items; 2. Choose one of them, and hold the MODE button for 5-10 seconds, then a tong will indicate to active TWS function. 3. Keep few seconds, when anther tong will indicate that TWS connected successfully.

**Note :** TWS only work under Bluetooth mode.

**USB/TF CARD:**

Insert the U flash memory or Micro-TF card into the USB/TF slot. it will read the MP3 format music automatically. Press ▶| to Play/Pause, press ◀◀ and ▶▶ to Prev and Next.

**CHARGING:**

Please use the original charging cable to charge, A red LED light will glow while charging & it will get full charged & it will turn OFF.

**IMPORTANT:**

When playing music during charging, please put the volume to middle, because for some music with heavy bass, the charger may not be able to afford the high current temporarily under the maximum volume.

**Warning:**

- Don't use/store this speaker in extreme temperatures.
- Please store it in cool and dry area, keep away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume.
- When cleaning this speaker, use a soft dry cloth. For more sever stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

