



# K1

Mechanical Gaming Keyboard



User Manual

## WHAT'S INSIDE THE BOX

- 1 x Wired Keyboard
- 1 x User Manual
- 1 x Warranty Card

## KEY LIGHTING EFFECTS

- 1. Fn Key + Insert**  
Effect 1: Full Keyboard Lighting  
Effect 2: Half Keyboard Lighting and Half Dark  
Effect 3: Full Keyboard Breathing  
Effect 4: Full Keyboard Lighting with the Pressed Key temporarily going Dark
- 2. Fn Key + Delete**  
Effect 1: Colorful Cloud Flow  
Effect 2: Circular Rotation of Lights around the Keyboard Center  
Effect 3: Left and Right Wave Patterns  
Effect 4: Flowing Water-Like Lights
- 3. Fn Key + Home**  
Effect 1: Press any key with full keyboard dark: Light spreads to entire area.  
Effect 2: Press any key with full keyboard dark: Pressed key lights up.  
Effect 3: Press any key with full keyboard dark: Horizontal spreading of light.  
Effect 4: Press any key with full keyboard dark: Heavenly Girl Scattered Flowers.
- 4. Fn Key + Pg Up**  
Effect 1: Horse Race  
Effect 2: Sinusoidal Beating  
Effect 3: Raining Drops  
Effect 4: Key-Centric Dark Wave - Full keyboard lights up; key presses trigger a dark wave centered on the pressed key.

- 5. Fn Key + Pg Dn**  
Effect 1: Twinkling Lights  
Effect 2: Water Surface Ripple  
Effect 3: Up-to-Down Wave  
Effect 4: Color Line Drifting

- 6. Fn Key + ScrLk**  
Effect 1: Horse Race Lap  
Effect 2: Rotating Light around Keyboard Center

- Increase/Decrease Backlight Brightness**
- Press **Fn Key + Up Arrow**: To increase backlight brightness.
  - Press **Fn Key + Down Arrow**: To decrease backlight brightness.
- Note:** LED indicator blinks 3 times at max/min brightness

- Increase/Decrease Backlight Effects Speed**
- Press **Fn Key + (=)** to increase the lighting effect speed.
  - Press **Fn Key + (-)** to decrease the lighting effect speed.
- Note:** LED indicator blinks 3 times at max/min brightness

- Keyboard Backlighting On/Off**
- Press **Fn Key + Pause** to toggle between switching on and off the keyboard backlighting

- Customizing Lighting Effects:**
1. Press **Fn Key + 4/5** to create two customizable lighting sets.
  2. Press **Fn Key + 4** to initiate the first lighting set.
  3. Press **Fn Key + End** to start recording lighting effects (LED indicator flashes).
  4. Press keys to select lighting (Press again to deselect).
  5. Press **Fn Key + End** to save your defined lighting effects.
  6. Repeat for a second lighting set with **Fn Key + 5**.

- Resetting to Default:**
- Long press **Fn Key + Esc** to reset to default mode (erasing custom lighting).

- Preset Lighting Effects:**
- Press **Fn Key + 1/2/3** to access preset lighting effects.

## TECHNICAL SPECIFICATIONS

Number of Keys	104 Keys
Switch Type	Blue & Tactile
Dimensions	440 mm x 135 mm x 27 mm
Cable Length	150 cm
Plug Type	USB-A
Material	ABS Plastic

## DO'S AND DON'TS

- Ensure the device remains dry and is shielded from rain, humidity, liquids, and condensation.
- Store the equipment within moderate temperature ranges; avoid high or low extremes.
- Do not use the device with wet hands.
- Do not use or store the device in dusty or dirty areas.
- Do not drop, knock or shake the device.



**www.portronics.com**  
**For Support**  
**Visit :** [www.portronics.com](http://www.portronics.com)  
**Email :** [help@portronics.com](mailto:help@portronics.com)  
**Contact No. :** +91 9555245245, 011-42413131  
(Working Hours. : Monday - Saturday 10:00am - 6:00pm)



**E-waste Management**

Email - [info@3recycler.com](mailto:info@3recycler.com)  
For E-waste & ROHS compliance refer to <http://www.portronics.com/ewaste.html>