



K2

Mechanical Gaming Keyboard



User Manual

WHAT'S INSIDE THE BOX

- 1 x Wired Keyboard
- 1 x User Manual
- 1 x Warranty Card

KEY LIGHTING EFFECTS

- 1. Fn Key + Insert**
Effect 1: Full Keyboard Lighting
Effect 2: Half Keyboard Lighting and Half Dark
Effect 3: Full Keyboard Breathing
Effect 4: Full Keyboard Lighting with the Pressed Key temporarily going Dark
- 2. Fn Key + Delete**
Effect 1: Colorful Cloud Flow
Effect 2: Circular Rotation of Lights around the Keyboard Center
Effect 3: Left and Right Wave Patterns
Effect 4: Flowing Water-Like Lights
- 3. Fn Key + Home**
Effect 1: Press any key with full keyboard dark: Light spreads to entire area.
Effect 2: Press any key with full keyboard dark: Pressed key lights up.
Effect 3: Press any key with full keyboard dark: Horizontal spreading of light.
Effect 4: Press any key with full keyboard dark: Heavenly Girl Scattered Flowers.
- 4. Fn Key + Pg Up**
Effect 1: Horse Race
Effect 2: Sinusoidal Beating
Effect 3: Raining Drops
Effect 4: Key-Centric Dark Wave - Full keyboard lights up; key presses trigger a dark wave centered on the pressed key.

- 5. Fn Key + Pg Dn**
Effect 1: Twinkling Lights
Effect 2: Water Surface Ripple
Effect 3: Up-to-Down Wave
Effect 4: Color Line Drifting
- 6. Fn Key + ScrLk**
Effect 1: Horse Race Lap
Effect 2: Rotating Light around Keyboard Center

- Increase/Decrease Backlight Brightness**
- Press **Fn Key + Up Arrow**: To increase backlight brightness.
 - Press **Fn Key + Down Arrow**: To decrease backlight brightness.
- Note:** LED indicator blinks 3 times at max/min brightness

- Increase/Decrease Backlight Effects Speed**
- Press **Fn Key + (=)** to increase the lighting effect speed.
 - Press **Fn Key + (-)** to decrease the lighting effect speed.
- Note:** LED indicator blinks 3 times at max/min brightness

- Keyboard Backlighting On/Off**
- Press **Fn Key + Pause** to toggle between switching on and off the keyboard backlighting

- Customizing Lighting Effects:**
1. Press **Fn Key + 4/5** to create two customizable lighting sets.
 2. Press **Fn Key + 4** to initiate the first lighting set.
 3. Press **Fn Key + End** to start recording lighting effects (LED indicator flashes).
 4. Press keys to select lighting (Press again to deselect).
 5. Press **Fn Key + End** to save your defined lighting effects.
 6. Repeat for a second lighting set with **Fn Key + 5**.

- Resetting to Default:**
- Long press **Fn Key + Esc** to reset to default mode (erasing custom lighting).

- Preset Lighting Effects:**
- Press **Fn Key + 1/2/3** to access preset lighting effects.

TECHNICAL SPECIFICATIONS

Number of Keys	104 Keys
Switch Type	Red & Linear
Dimensions	440 mm x 135 mm x 27 mm
Cable Length	150 cm
Plug Type	USB-A
Material	ABS Plastic

DO'S AND DON'TS

- Ensure the device remains dry and is shielded from rain, humidity, liquids, and condensation.
- Store the equipment within moderate temperature ranges; avoid high or low extremes.
- Do not use the device with wet hands.
- Do not use or store the device in dusty or dirty areas.
- Do not drop, knock or shake the device.



www.portronics.com
For Support
Visit : www.portronics.com
Email : help@portronics.com
Contact No. : +91 9555245245, 011-42413131
(Working Hours. : Monday - Saturday 10:00am - 6:00pm)



E-waste Management
Email - info@3recycler.com

For E-waste & ROHS compliance refer to
<http://www.portronics.com/ewaste.html>