


KEY11 COMBO

WIRELESS KEYBOARD & MOUSE



User Manual

Package Contents

- Wireless Keyboard x 1
- Wireless Mouse x 1
- USB Receiver x 1
- User Manual x 1

Setting And Operation Instructions

» How to use

- Keyboard can connect to 3 devices, short press the pairing key to switch back and forth between 2.4G/BT1/BT2 modes;
- The current working channel can be determined by the different colors displayed on the LED: 2.4G: Green light BT1: Blue light BT2: Orange light

» 2.4 GHz USB Receiver Mode

When turned on, it defaults to 2.4G working mode for keyboard and mouse. Simply plug the USB receiver into the computer to start working.

» Bluetooth Mode for Keyboard

- Short press the pairing key to enter BT mode, and the corresponding LED indicator light will flash once and turn off. Then, long press the pairing key for 3 seconds, and the corresponding LED indicator light will flash quickly to enter pairing mode (pairing time is 2 minutes).

- Search for "Key11 BT1" or "Key11 BT2" in the device, click "pairing" to connect and use. After successful pairing, the corresponding LED light will stay on for 2 seconds and then turn off.(Prioritize Key11 BT1 connection)

When the keyboard enters BT mode, two BT device names (Key11 BT1/Key11 BT2 keyboard) can be found. It is recommended to prioritize selecting the "Key11 BT1" for pairing.

» Bluetooth Mode for Mouse

- Switch to the BT mode from the bottom of the mouse, and the corresponding blue LED indicator light will flash once and turn off. Then, long press the pairing key for 3 seconds, and the corresponding blue LED indicator light will flash quickly to enter pairing mode (pairing time is 2 minutes).
- Search for "BT5.0 Mouse/BT3.0 Mouse" in the device, click "pairing" to connect and use. After successful pairing, the corresponding blue LED light will stay on for 2 seconds and then turn off.(Prioritize BT5.0 Mouse connection)
- When the mouse enters BT mode, two BT device names (BT5.0 Mouse/BT3.0 Mouse) can be found. It is recommended to prioritize selecting the "BT5.0 Mouse" for pairing.

» Attention

- When the keyboard/mouse switches to BT mode for the first time, it directly enters pairing mode, and the corresponding LED indicator

light is in a flashing state. When the device searches for the BT name, click "pairing" to connect and use it.

- If the keyboard/mouse is already connected to a device in BT mode and the device has not been deleted or unpaired, when switching to BT mode, the device will automatically reconnect and can be used immediately.

- Priority should be given to connecting to BT5.0 on WIN10/11. Some old computers may not be able to find BT5.0, so simply connect to BT3.0.

Function Multimedia Hotkeys

- Fn + F1 = Music player
- Fn + F2 = Volume down
- Fn + F3 = Volume up
- Fn + F4 = Mute
- Fn + F5 = Previous track
- Fn + F6 = Next track
- Fn + F7 = Play/pause
- Fn + F8 = Stop
- Fn + F9 = Homepage
- Fn + F10 = E-mail
- Fn + F11 = My computer
- Fn + F12 = Favorite

» Sleep mode

If there is no key operation on the keyboard for 5 seconds/mouse for 3 seconds, it enters sleep mode and all indicator lights are off; Pressing any button again will automatically restore it to its original state.

» Low voltage indication

When the voltage of the keyboard/mouse drops below to 3.2V, the red LED flashes.

» Charging the keyboard/mouse

Suggest using a USB-Type-C data cable to connect to a computer for charging (mobile phone charger is not recommended).

» Troubleshooting

- If the keyboard and mouse combo doesn't work, try the following:
 - Check if the battery of the keyboard and mouse combo is low. If so, please charge it first. It can work simultaneously while charging.
 - Check if the USB receiver is plugged into the computer's USB port. If so, please try connecting to a different USB port.
- If the feedback of keyboard and mouse combo is slow or unresponsive:
 - Increase the distance between the keyboard and mouse combo and any other wireless device.
 - Certain metal surfaces may interfere.
 - The keyboard and mouse combo and receiver can delay response time.

Warning

Before using this product, please read all instructions and warnings. Always keep dry. Do not attempt to insert foreign objects into the device. Do not disassemble or attempt to repair equipment

Note: Any damage caused by physical impact, water / liquid, fire, etc. caused by the customer or nature shall not be covered under warranty. Only product design, feature and functionality-related faults can be considered. During the warranty period, this product is only eligible for replacement and not eligible for repair, as per the brand's discretion.



www.portronics.com

For Support

Visit : www.portronics.com

E-mail : help@portronics.com

Contact No.: +91 9555245245

(Working Hours: Monday – Saturday, 10:00am – 6:00pm)



E-Waste Management
E: info@3rrecycler.com
For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste