# PORTRONICS




LUMISTICK PRO Adjustable Smart Selfiestick

User Manual

## COMPATIBLE WITH



## PHONE VOLUME KEY PHOTOGRAPHY SETTING



# The State of the S

## HOW TO USE

- Sounds & vibration

Do Not Disturb

Ring

\_\_\_

\_

Default volume button

Default volume button control

CANCEL

Alarms

- Startup: Press and hold the camera button for 3 seconds to start the machine. The indicator will flash to enter search mode.
- Bluetooth connection: Open the Bluetooth settings on your mobile phone. Search for "selfie" and click to connect. Once the connection is successful, the indicator light will turn off.
- Photographing: When the remote control is connected to the mobile phone, click the photographing button. The indicator will flash, and the camera will take a picture.
- Shutdown without connection: If the remote control remains disconnected and inactive for approximately 5 minutes, it will automatically shut down.
- Connected shutdown: When the remote control is connected to the mobile phone and remains inactive for approximately 10 minutes, it will automatically enter sleep mode. If there's no further activity within another 10

minutes, the device will shut down.

- 6. Sleep: To connect the mobile phone after entering sleep mode, press the photo key.
- Shutdown: While in the power on or sleep state, long
  press the photo key for 3 seconds. The indicator will flash
  off, and the device will shut down.
- Back connection function: The remote control features automatic reconnection. When your mobile phone's Bluetooth is enabled, the remote control will automatically connect to the previously paired device.

## PRODUCT PARAMETERS

- Width of holding mobile phone: 65 90 mm
  Supported mobile phone size: 4.7 7 inches
  - REMOTE CONTROL PARAMETERS

Charging condition: 5v 1A

Battery capacity: 55mAh

Charging current: About 50mA

Full charge time: about 30-60 minutes
Bluetooth Name: selfie

- Solution to the case of failure of remote control to connect to mobile phone:
- Enable Bluetooth on your mobile phone and clear any paired devices.
- 2. Power off and restart your phone.
- 3. Power off and restart your Bluetooth remote control.
- 4. Re-enable the Bluetooth connection.
- 5. With Bluetooth enabled on both your mobile phone and remote control, search for the mobile phone on your remote control. When you find it, click "Connect." If the interface displays "connecting," press the remote control button continuously and quickly. This should establish a normal connection. (Note: This initial pairing process is required. Future connections will be automatic.)
- For Android phones, resolve quantity/focus adjustment and/or no response issues by adding the sound solution:
- 1. Open the camera and enter the photographing interface.
- 2. Swipe left or find the camera settings.
- 3. Click the volume key function.
- 4. Set the volume key function to shutter (do not select zoom or focus).
- 5. Individual mobile camera setting paths may vary. Please locate the appropriate settings for your device.
- This remote control supports only the video recording function of mobile cameras. It does not support the video recording function of live streaming apps.
- · Operation method:
- Connect the Bluetooth remote control to your mobile phone.

- Open the camera app on your mobile phone or download another camera app.
- Switch to video mode.
- Click the remote control button to start recording the video.
- 5. Click the button again to stop the video recording.

Usage status: The blue light flashes, turns off after connecting to the mobile phone. Click to take pictures, and the blue light flashes.

Charging status: The red light stays on while charging. When fully charged, the red light turns off.

- Operating mode:
- 1. Remote control, effective distance 10m
- Tripod mode
- 3. Handheld mode



### www.portronics.com

For Support
Visit: www.portronics.com
Email: help@portronics.com

Contact No.: +91 9555245245 (Working Hrs.: Monday - Saturday 10:00am - 6:00pm)



E-Waste Management E: info@3rrecycler.com For E-Waste & ROHS compliance refer to www.portronics.com/ewaste