

Luxcell Magclick 10K

10000mAh Power Bank



Thank-you for choosing Portronics.

We're happy to help you understand how to use
this product. Read on!

User Manual

Package Contents:

- 1. Power Bank
- 2. Charging Cable
- 3. User Manual

Luxcell Wireless Mini

- 1. Digital Display
- 2. USB Output
- 3. Type-C Input
- 4. Wakeup Button
- 5. Magnetic Wireless Charging Area

Charging Your Devices

A button is located on the Top of the Power Bank.

 When the button is pressed, the Digital LED display will display the remaining battery capacity, and it also powers on the Power Bank.

- The Digital Display turn off by double pressing the power button.
- To charge your mobile phone with this Power Bank, simply connect the charging cable provided.

Charging the Power Bank

To charge your powerbank, connect the Type C port located on the Power Bank to the USB-A port on a computer or USB charger, using the Charging cable provided.

DOS and DON'Ts

- Make sure the Power Bank is fully charged prior to use.
- Use a cable suitable for your device when charging it from the Power Bank.
- When charging the Power Bank, it is recommended that you use the included charging cable.
- Recharge the Power Bank as soon as possible to avoid

shortening the battery life.

- The battery should be charged at least every three months to avoid shortening the battery life.
- Do not wash the Power Bank with corrosive cleaner.

Technical Specifications:

Capacity: 10000mAh

Input (Type-C): DC 5V:::3A/ 9V:::2A

Output (Type-C): DC 5V::-3A/ 9V::-2.22A/ 12V::-1.67A(20W MAX.)
Output (USB): DC 5V::-3A/ 9V::-2A/ 12V::-1.5A/ 10V::-2.25A(22.5W MAX.)

Magsafe Output: 5W/7.5W/10W/15W
Max Output(Type-C + USB-A): DC 5V-3A





E: info@3rrecycler.com
For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste

www.portronics.com For Support

Visit: www.portronics.com E-mail: help@portronics.com Contact No.: +91 9555245245

(Working Hours: Monday - Saturday, 10:00am - 6:00pm)