

**PICO 12**  
Portable LED Projector

**User Manual**




**【Attention】**

Please read this manual carefully before use and keep it for future reference.

- 1.The projector is non dustproof or non waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.


**【Structure description】**

The picture and function description of the projector are for reference only. It is subject to change without prior notice.




**【Power ON/OFF】**

Press ON/OFF button to turn it on, then press promptly to turn it off.



**【Settings】**

Enter settings for Networking, Bluetooth, Language, Projection, Bluetooth Speaker, Date And Time, Other Setting, About us.




**【WIFI Setting】**

1. Settings - Network Setting - WIFI setting, WIFI "ON";
2. Scroll the WIFI list to select WIFI ID and input password to connection internet.




**【Bluetooth Setting】**

Settings - Bluetooth setting, Bluetooth "ON", click "Refresh Device" and search for device pairing until it is connected.



**【Bluetooth Speaker Mode】**

Settings - Bluetooth Speaker - Press Speaker Mode: Close to go Bluetooth Speaker Mode(Voice broadcast: Bluetooth device is ready to pair)




Bluetooth Name : PICO 12  
Speaker Mode: Close

Turn on smartphone and search Bluetooth device, Select "Bluetooth Name"and start pairing, there will be a voice broadcast after paired: Bluetooth device is connected successfully.

Press remote control " " or " " button to quit "Bluetooth Speaker Mode".


**【Language Setting】**

Settings - Language - Setup Language Settings and Input Selector.




**【Other Setting】**

Setting - Other Setting - Application and Factory Reset are available.



**【Projection Setting】**

Setting - Projection - Setup Screen Zoom, Projection Mode, Keystone, Pointer Speed, Brightness, Wind Speed.



**【HDMI IN】**

This is an HDMI-enabled product,HDMI IN function, mainly input the signal from other equipment into the projector to cast on screen. This projector is HDMI input, please make sure your other equipment is HDMI output. Come to projector menu and click "HDMI" icon to enter HDMI mode.



**Dos and Don'ts :**

To ensure safe operations for your projector, please follow these rules :

1. Always place the projector in a safe location.
2. Do not peak into the projector lens when it's in use, as it may cause damage.
3. When not in use, switch off the projector and unplug it from the power source.
4. If the product is defective, kindly do not attempt to fix it yourself, we recommend professional help.
5. Keep the product away from water, to not cause internal damage.

[www.portronics.com](http://www.portronics.com)

For Support  
Visit : [www.portronics.com](http://www.portronics.com)  
Email : [help@portronics.com](mailto:help@portronics.com)  
Contact No. : +91 9555245245 , 011-42413131  
(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)

