



# Resonate


## 14W Wireless Bluetooth Speaker

User Manual

### Package Contains

- ⇒ Portable Wireless Speaker 1 N
- ⇒ Charging Cable 1 N
- ⇒ User Manual 1 N

### Product Details



1. Type-C Charging Jack
2. USB Port
3. Backward/Volume Down
4. Forward/Volume Up
5. Play/Pause
6. Mode Button (turn among Bluetooth, USB disk)
7. Power On/Off

### Bluetooth Mode

**1. Power Button**

- Long-press for Power On/Off. Activate Bluetooth of mobile phone and pair with the speaker.

**2. Mode Button**

- Short-press to switch playing modes, Long-press to pair or disconnect TWS.

**3. Play/Pause**

- Short-press to play or pause, Long-press to disconnect and reconnect the Bluetooth connection with the mobile device fast double-press to activate voice assistant function.

**4. Backward/Volume Down**

- Short-press for volume down, Long-press for last song.

**5. Forward/Volume Up**

- Short-press for volume up, Long-press for next song.

**Note:**  
If your smartphone is disconnected from speaker due to shutdown or switching mode, the speaker will automatically reconnect your smartphone when it is turned on again or switched back to Bluetooth mode.

### TWS Mode

Turn on 2 identical speakers, both under BT mode. Select one speaker and Long-press Mode button (for 2 seconds) to start TWS function, the speaker will make a tone to start to pair, and there will be a prompt tone again after paired successfully. Connect the paired speaker with your phone via Bluetooth and play wirelessly.

Long-press Mode button (for 2 seconds) again to disconnect TWS.

**1. Mode Button**

- Long-press to pair or disconnect TWS, Short-press to switch playing modes.

**2. Play/Pause**

- Short-press to play or pause, Long-press to disconnect and reconnect the Bluetooth connection with the mobile device.

**3. Backward/Volume Down**

- Short-press for volume down, Long-press for last song.

**4. Forward/Volume Up**

- Short-press for volume up, Long-press for next song.

**Note:**  
If TWS is disconnected from speaker due to shutdown or switching mode, they will automatically reconnect when they are turned on again or switched back to Bluetooth mode.

### Sunset Lamp

You can switch below different modes of LED illumination (include Off) by Short-Press button

- **Mode 1:** Sunset light on constantly
- **Mode 2:** Green light on constantly
- **Mode 3:** Purple light on constantly
- **Mode 4:** Sunset light flash Breathing
- **Mode 5:** RGB lights rhythm flash and follow the beat of playing music.

The device will automatically enter mode 1 when powered on.

### Hands-free call

1. Under Bluetooth connection status, if there is an incoming call, user can short-press Play/Pause button to accept the call or long-press Play/Pause button to reject the call.

2. During the call, user can long-press Play/Pause button to switch to talking on the phone.

2. Short-press Play/Pause button to end the call.

### Reset Functionality

1. Long-press button Volume Down for more than 5 seconds, device will power off. Meanwhile it will clear all Bluetooth & TWS connection memory, and restore factory setting.

### How to charge

1. The charger is not included in the package, please charge this speaker via a rated 5V/2A charger.
2. Charge time should be around 3 hours.
3. To protect the battery, please do not use the speaker while it is charging.

### USB Mode

- 1. Power Button**

  - Long-press for Power On/Off

- 2. Mode Button**

  - Short-press to switch the playing modes

- 3. Play/Pause**

  - Short-press to play or pause

- 4. Backward/Volume Down**

  - Short-press for volume down, Long-press for last song

- 5. Forward/Volume Up**

  - Short-press for volume up, Long-press for next song

**Note:**  
Under any playing mode, when you insert a USB disk to the speaker, it will switch to play the USB disk.

### Features:

1. Bluetooth 5.3 for more stable, faster and stronger compatibility on connection
2. Texture Portable Speaker with Sunset Lamp
3. Emitting Endless Comfort and Coziness
4. Multiple Sunset Lamp Modes
5. Leather handle for easy carrying
6. TWS function, achieve true wireless playing with double enhanced stereo sound
7. With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device
8. Hands-free Mic for easy picking up the call
9. Optimized voice assistant control
10. USB support
11. Built-in lithium rechargeable battery 2000mAh

### Specifications:

- Bluetooth Version** ⇒ V5.3
- Speaker Size** ⇒ 2.75 inch\*1
- Tweeter Size** ⇒ 27mm\*1
- Peak power output** ⇒ 14W
- Battery Capacity** ⇒ 3.7V, 2000mAh
- Frequency Response** ⇒ 80HZ-16KHZ
- Size** ⇒ 179\*(L)\*141(H)\*77.5(W)mm

### Warning

1. Please store and use this product in an environment of normal temperature.
2. Please do not expose this product to rain or moisture environment.
3. Please do not disassemble, repair or modify this product by yourself without authorization.
4. When cleaning this product, please use a soft cloth or with little water if needed, please do not use chemicals for cleaning.
5. In order to have an extended product life and protect your hearing, please avoid listening to songs on maximum volume for long time.
6. The product is with built-in lithium battery, to avoid dangers, please do not discard or put it in the fire.