



Resound

5W Portable Speaker with FM



User Manual

Package Contents :

- Wireless Speaker
- Charging Cable
- User Manual
- Aux Cable

Product Features :

1. International advanced bluetooth chip and circuit design techniques, support all wireless devices.
2. With FM function, can search radio station broadcast automatically
3. With Hi-Fi speaker, to make sure the clear and bright sound.
4. Support Micro SD card and USB card, play MP3 format audio.
5. The wireless working distance is 10 meters.
6. With AUX line in, can directly connect the outside devices, for example, table PC/TV/cell phones.
7. It will close automatically after 30 mins if disconnect wireless & torchlight not working
8. A variety of flashing LED lights with different colors, color lights flash follow the melody.
9. Support TWS.


Key and Slot Function

1. International advanced bluetooth chip and circuit design techniques, support all wireless devices.
2. With FM function, can search radio station broadcast automatically
3. With Hi-Fi speaker, to make sure the clear and bright sound.
4. Support Micro SD card and USB card, play MP3 format audio.
5. The wireless working distance is 10 meters.
6. With AUX line in, can directly connect the outside devices, for example, table PC/cell phones.
7. It will close automatically after 30 mins if disconnect wireless working .
8. A variety of flashing LED lights with different colors, color lights flash follow the melody.
9. Support TWS.

Key and Slot Function

1. DC 5V slot: Use the standard Micro USB _ charging cable for power charging.
2. TF Slot: It can decode and play MP3 format audio when put TF card into the slot.
3. USB Slot: It can decode and play MP3 format audio when put the USB card into the slot.
4. AUX line in slot: Use the Mini 3.5 head input through outside devices.

5. Power switch : Press long for power on /power off. When play music, (USB card/TFcard/Wireless/line in), short press for "play/pause". In FM mode, press short to search station automatically, press again to hand up, press twice to ring up a call.



6. When play music, press short for last song, long press to turn down the volume.
7. When play music, press short for next song, long press to turn up the volume.
8. LED Switch: press short for option of the LED flashing light, press long to close/open the LED light.
9. Short press to switch model (USB card/TF card/Wireless/line in/ FM).

TWS Keep the two speaker under Wireless mode without pairing, press the "M" key for 2-3 seconds either of the speaker until hear a hint and mean-time the button light stop flashing, now it is TWS mode, then can pair the mobile.

NOTE : If speaker crash, it can be reset by short pressing the reset button built-in the line-in hole with some tool. or long pressing the power button for 8 seconds.
USB/TF card please use FAT32 format.

Specifications :

Bluetooth Version	: V5.3
Support	: L2CAP/A2DP AVCTP/AVDTP/AVRCP)HSP/HFP
Product weight	: 332 g
Battery	: 1800mAh/3.7V
Play Time	: Up to 6-8 Hrs
SN Ratio	: >=90db
Output	: 5W
Frequency Response	: 120HZ-20KHZ
Charging voltage	: DC 5V-500mA
Charging time	: Up to 5 Hrs
speaker size	: 111*111*87 mm

DOS AND DON'TS

To ensure safe operations for your speaker, please follow these rules:

1. Always place the speaker in a safe location.
2. Avoid excessive pressure on either equipment.
3. When not in use, switch off the speaker and unplug them from the power source.

4. If the product is defective, kindly do not attempt to fix it yourself. We recommended professional help.
5. Keep the product away from water, to avoid internal damage.



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245, 011-42413131

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-waste Management

Email - info@3recycler.com

For E-waste & ROHS compliance refer to <http://www.portronics.com/ewaste.html>