




TOAD III PLUS

Rechargeable Wireless Mouse




User Manual

I. Package Contents

- 1 x Wireless Mouse
- 1 x USB Receiver
- 1 x Charging Cable
- 1 x User Manual

II. Physical Specifications



- 1 - Left & Right Buttons
- 2 - Scroll Wheel
- 3 - Power On-Off
- 4 - Connectivity Mode Button
- 5 - Type-C Charging Port
- 6 - Adjustable DPI Button
- 7 - USB Receiver Compartment
- 8 - Forward Button
- 9 - Backward Button

III. Charging The Mouse

The Portronics Toad III Plus is a rechargeable wireless mouse; connect the charging cable (provided in box) to a phone charger (not provided) to charge the mouse. It is recommended to charge the mouse for 3 hours before first use.

Please note : Do not use a Type-C to Type-C charging cable to charge the wireless mouse.

IV. Setting up 2.4 GHz Wireless Mode

- Toggle the power switch to the "ON" position and press the Connectivity Mode Button to enter 2.4 GHz wireless connectivity mode with green light flashing.
- Insert the receiver into a USB port on your computer and press any mouse button to activate.
- If connection successful, the red LED light at the bottom of the mouse will illuminate.

V. Setting up the Bluetooth Mode

- Toggle the power switch to the "ON" position and press the Connectivity Mode Button to enter the Bluetooth connectivity mode with the blue light flashing.
- Long press the Connectivity Mode Button to enter the Bluetooth Pairing Mode and the blue light begins flashing quickly. Note: For first time pairing, the mouse automatically enters pairing mode automatically.

- Scan for Bluetooth devices on your device (such as laptop, desktop, tablet or smartphone) and select to pair with "Toad III Plus" to connect with the wireless mouse.
- The wireless mouse is ready to use once the it is paired with your device via Bluetooth.

VI. Switching between Connectivity Modes

Press the Connectivity Mode button to switch between Bluetooth and 2.4 GHz wireless connectivity modes.

VII. Adjusting Mouse Sensitivity

Press the DPI Button below the scroll wheel to cycle through three different mouse sensitivity levels of 800 DPI, 1200 DPI and 1600 DPI.

VIII. Forward & Backward Buttons

The 2 buttons located near the grip of the mouse on the left side operate as forward and backward commands



E-Waste Management
E: info@3rrecycler.com
For E-Waste & ROHS compliance refer to www.portronics.com/ewaste

www.portronics.com

For Support

Visit : www.portronics.com

E-mail : help@portronics.com

Contact No.: +91 9555245245

(Working Hours: Monday - Saturday, 10:00am - 6:00pm)