

# HYDRA 10



Gaming Wireless Key Board

**Note:** First charge the keyboard using the wire provided. Type C charging jack.



When the SPACE key turns green while charging it means the device is fully charged (100%).



Red light flashing on the SPACE key indicates low battery and it means the charging has to be set up.



Blue Light on the SPACE key indicates the successful charging process of the keyboard.



### FOR WIRED MODE

Off mode to On mode followed by using the provided wire as a connection between the keyboard and the PC or Laptop.



Note : Press the FN and TAB key to switch from wired to wireless connection.



### FOR RF MODE or 2.4G CONNECTION

**Note:** Dongle is provided in the slot behind the keyboard. First time connection, FN+tab, then FN+R and FN+P, then plug receiver to computer, it will get connected.

2.4G repair: Fn+ tab, then FN+R, it will get reconnected



Insert the provided dongle connector and your keyboard is all ready to be used.



### FOR BT MODE

**Note:** 3 Keys on the keyboard, Q, W, and E are dedicated for bluetooth mode.

Press the FN and TAB keys.



Now press FN+Q/W/E (Either Q, W or E) and



After that press FN and P keys to make the keyboard visible to the source device.




After the name pop-up, pair the keyboard with the PC or Laptop or Smartphones or Tablets.



### LED Mode For Lighting Effect (20 modes all in all)

LED Backlight Effect

Press the FN and  to activate the LED backlights and keep it pressed for different light modes.



To stop the lights press the FN and X keys simultaneously.



**Note:** There are 5 levels of brightness in the LED backlight mode. To increase the brightness, press the FN and Up Arrow Key on the lower side of the keyboard.



When you are on the maximum level of brightness the CAPS and WIN keys start flashing simultaneously and to decrease the brightness vice versa.

### CONTROLLING THE MOVEMENTS OF THE LIGHTING MODES

Press the FN and Right Arrow Key till you see the desired

